

## SmartPAT 5000 & 3000 PAT Testers

The **SmartPAT 5000** and **SmartPAT 3000** have been widely accepted for commercial Portable Appliance Testing requirements.

**SmartPAT 5000** is purpose built to handle hundreds of appliance test results. Just enter one of the pre-programmed test codes and **SmartPAT 5000** will guide you through the test sequence. Nothing could be easier.

In addition to its pre-programmed test sequences, **SmartPAT 5000** is fully programmable allowing the user to formulate unique test sequences for specific applications. At any point the **SmartPAT 5000's** unique dedicated help facility can be called up to give instant user assistance.

SmartPAT 5000/3000

33

PAT Testing



SmartPAT 5000

### SmartPAT 5000



Results of each test are assigned unique references and stored in the on-board computer. When testing is complete, results can be downloaded to a computer using Robin's **PowerPAT Plus** Software or directly printed out on Robin's **SP1000** printer or other compatible serial printer.

Using the optional wide-head barcode scanner, appliance number, site details and test sequences can be rapidly entered directly into **SmartPAT 5000**.



SmartPAT 3000

### SmartPAT 3000



**SmartPAT 3000** is a cost effective, user friendly PAT that will perform all the tests required for Class I and II appliances.

**SmartPAT 3000** features include 110V and 240V appliance tests, an IEC lead test and a 100mA business equipment earth bond test for portable appliances typically found in modern commercial office environments.

SmartPAT Comparator	5000	3000
Earth bond test	●	●
100mA business equipment test	●	●
Insulation test	●	●
P-N continuity	●	●
Earth leakage	●	●
Tests 110V and 240V appliances	●	●
Flash test	●	●
Downloads to a computer or printer	●	●
On board help	●	●
IEC lead test	●	●
Reads any barcode up to 10 digits	●	●